

Innovative Royal Big Button 2018

Base Part Number: R12060B00-00001

Configured Part Number: R12060BA00-00019

Artwork **UEI Simple Innovative** 01

PN: 2060B-00019
Dimensions: 214 x 60 x 34 mm
Designer: Rex Xu
PM/AE: Jeannine Hawes
Date: 2/28/2018

Revisions:
Initial Release

PANTONE®

Top Case Color
Pure Black Matte Finish

Bottom Case & Battery Door
Pure Black Matte Finish

Keypad Colors
Translucent Matte Finish

Keypad Print
Pure Black Matte Finish

Blue 233 U Matte Finish

Green 342 U Matte Finish

Yellow 109 U Matte Finish

Topback Case Print
Pure White Matte Finish

NOTE: Colors on rendering are for reference only. Please refer to Pantone color book for true colors.



UNIVERSAL ELECTRONICS. This rendering is for reference only. It is not to scale and design features may vary upon engineering review. This is Proprietary Information of Universal Electronics Inc. **CONCEPTUAL & CONFIDENTIAL.**

Functionality Requirements

1.1 Programming Remote to a Specific STB

In order to program this remote control to a specific STB, hold SET UP plus the corresponding colored action key until the CABLE POWER key blinks twice.

Action Key	Manufacturer
A/YELLOW	Amino
B/BLUE	Innovative Systems, Motorola
C/RED	ADB
D/GREEN	Entone

1.2 Default Devices

Device	Default Device Code
Cable (Default)	Amino C1898
TV	Samsung T0812

1.3 QuickSwap Codes

The action keys (A-D) can store up to four (4) codes. This feature allows the installer to easily change the default code programmed under the Cable (STB) key to another cable code. The chart below shows the configured quick swap codes.

Action Key	Manufacturer	IR Code
A/YELLOW	Amino	C1898
B/BLUE	Innovative Systems, Motorola	C1376
C/RED	ADB	C2254
D/GREEN	Entone	C4437

1.4 Volume Lock

By default the remote control has Volume Lock set to the TV mode which allows you to control the TV's volume when the remote is in Cable or TV mode. This feature can be changed to lock the volume to other modes.

Volume Lock	Setting (Yes, No)	Mode
Volume Locked	Yes	TV

1.5 On Demand Key

Key can send a channel number or IR function*

IR function - On demand-*See key chart

Keychart

Key Labels	Amino Address 0 C1898	Innovative Systems, Motorola C1376
	Quick Swap A-Default	Quick Swap B
SETUP	-----	-----
TV POWER	TV Power	TV Power
CABLE POWER	Power	Power
GUIDE	Guide	Guide
MENU	Menu	Menu-Settings
INFO	Info	Info
MENU UP	Menu-Focus Text Page Up	Menu Up
MENU DOWN	Menu-Focus-Text Page Down	Menu Down
MENU LEFT	Menu-Focus Left	Menu Left
MENU RIGHT	Menu-Focus Right	Menu Right
OK\SELECT	OK	OK-Select
EXIT	Exit	Exit-Back
FAV	Favorite	Favorite
A	A-Fastext Yellow	A-Yellow-Audio-Language
B	B-Fastext Blue	B-Blue-Subtitle-CC
C	C-Fastext Red	C-Red
D	D-Fastext Green	D-Green-W
VOLUME UP	TV Volume Up	TV Volume Up
VOLUME DOWN	TV Volume Down	TV Volume Down
MUTE	TV Mute	TV Mute
ON DEMAND	On Demand	On Demand-VOD
CHANNEL UP	Channel-Program Up	Channel Up
CHANNEL DOWN	Channel-Program Down	Channel Down
LAST	Delete-Last-Previous Program	Last Channel
REWIND	Search Reverse-Text Off	Search Reverse-Rewind
PLAY	Play-Text	Play
FFWD	Search Forward-Text Mix	Search-Fast Forward
STOP	Stop-Text Expand	Stop
PAUSE	Pause-Text Hold	Pause-Play
REC	Record	Record

1	Digit 1	Digit 1
2	Digit 2	Digit 2
3	Digit 3	Digit 3
4	Digit 4	Digit 4
5	Digit 5	Digit 5
6	Digit 6	Digit 6
7	Digit 7	Digit 7
8	Digit 8	Digit8
9	Digit 9	Digit 9
0	Digit 0	Digit 0
TV INPUT	TV Input	TV Input
CC	#	Aspect-HD Zoom

Key Labels	ADB C2254	Entone C4437
	Quick Swap C	Quick Swap D
SETUP	-----	-----
TV POWER	TV Power	TV Power
CABLE POWER	Power	Power
GUIDE	Guide	Guide
MENU	Menu	Menu
INFO	Info	Info
MENU UP	Menu Up	Menu Up
MENU DOWN	Menu Down	Menu Down
MENU LEFT	Menu Left	Menu Left
MENU RIGHT	Menu Right	Menu Right
OK\SELECT	OK	Select
EXIT	Exit	Exit
FAV	My Media Network	Options
A	Fastext Yellow	A-Yellow
B	Fastext Blue	B-Blue
C	Fastext Red	C-Red
D	Fastext Green	D-Green
VOLUME UP	TV Volume Up	TV Volume Up
VOLUME DOWN	TV Volume Down	TV Volume Down
MUTE	TV Mute	TV Mute
ON DEMAND	VOD	Movies
CHANNEL UP	Channel Up	Channel-Page Up
CHANNEL DOWN	Channel Down	Channel-Page Down
LAST	Last	Last
REWIND	Rewind	Rewind
PLAY	Play	Play
FFWD	Fast Forward	Fast Forward
STOP	Stop	Stop
PAUSE	Pause	Pause

REC	Record	Record
1	Digit 1	Digit 1
2	Digit 2	Digit 2
3	Digit 3	Digit 3
4	Digit 4	Digit 4
5	Digit 5	Digit 5
6	Digit 6	Digit 6
7	Digit 7	Digit 7
8	Digit 8	Digit 8
9	Digit 9	Digit 9
0	Digit 0	Digit 0
TV INPUT	TV Input	TV Input
CC	#	CC

Appendix A: Artwork

Artwork **UEI Simple Innovative** 01

PN: 2060B-00019
 Dimensions: 214 x 60 x 34 mm
 Designer: Rex Xu
 PM/AE: Jeannine Hawes
 Date: 2/28/2018

Revisions:
 Initial Release

PANTONE

Top Case Color
 Pure Black Matte Finish

Bottom Case & Battery Door
 Pure Black Matte Finish

Keypad Colors
 Transparent Matte Finish

Keypad Print
 Pure Black Matte Finish
 Red 199 U Matte Finish
 Blue 282 U Matte Finish
 Green 342 U Matte Finish
 Yellow 109 U Matte Finish

Top/Back Case Print
 Pure White Matte Finish

NOTE: Colors on rendering are for reference only. Please refer to Pantone color book for true colors.

